



RAYCORE-SHEAR TRANSFER AT WOOD FLOOR

SCALE: 1:10

SF FL1 Raycore shear xfer at floor-US

NOTES:

(1) ALL DIMENSIONS ARE IN INCHES UNLESS NOTED OTHERWISE.

(2) THIS DETAIL APPLIES TO CONVENTIONAL 1-SIDED SHEARWALLS OR BRACED WALL PANELS ONLY.

FOR 2-SIDED SHEARWALLS CONSULT A STRUCTURAL ENGINEER.

(3) WALL PERPENDICULAR TO JOIST CONDITION SHOWN, PARALLEL CONDITION IS SIMILAR.