

305 East Elva Street • Idaho Falls, Idaho 83401 877.552.2440 • info@raycore.com

Permission granted for RAY-CORE projects only. © RAY-CORE, INC.

DETAIL NO. BY


SF R7 Raycore attachment to rafter-truss-par-US

KPL/Alpen Engineering, Inc.

2/26/18 DATE

REVISION DATE

STRUCTURAL DETAIL



RAYCORE ATTACHMENT TO PARALLEL RAFTER OR TRUSS

SCALE: 1" = 1'-0"

SF R7 Raycore attachment to rafter-truss-par-US

- (1) ALL DIMENSIONS ARE IN INCH UNLESS NOTED OTHERWISE
- (2) THIS DETAIL SHOWS HOW TO INSTALL PANELS WITH LONG AXIS & SLEEPERS PARALLEL TO RAFTERS OR TRUSSES. HOWEVER, FOR MOST INSTALLATIONS, PLACING PANELS TRANSVERSE TO THE RAFTERS OR TRUSSES WILL BE EASIER & SIMPLER.
- (3) ADDITIONAL SCREWS MAY BE NECESSARY ON PITCHED ROOFS WITH SIGNIFICANT SNOW LOADS. DESIGNER OR ENGINEER SHALL CHECK SCREW SPECIFICATION FOR IN-PLANE LOADS FROM SNOW.